


Cine Tripod: Adjusting Leg Pivot Friction

C1221-4980 Issue 1


oconnor

www.ocon.com


1. Release the leg friction lever.



2. Supporting the friction lever with one hand, strike the end of the lever with the palm of the other hand, to release the adjustment nut.



3. Rotate the adjustment nut clockwise to increase pivot friction or counterclockwise to decrease pivot friction.



4. Reapply the leg friction lever. Check the leg pivot friction and readjust as necessary.

